

Tips for Magnetic Vinyl Uses

Preparation:

1. Prepare the surface of the vehicle and the brown magnetic side of the sign by cleaning, drying and waxing before application.

Installation:

1. The magnetic sign should have full contact with a steel surface. Make contact with on edge first and gently let the full sign rest on the metal surface, removing all air pockets. For re-alignment, remove the full sign and start over. Do not pull the magnetic sign to straighten as it may stretch and disfigure it.
2. The magnetic sign should be at room temperature when applied to a steel surface.
3. Do not apply magnetic over molding, nuts, bolts, or rivets.
4. Do not apply magnetic over newly painted surfaces (allow 3 months for paint to cure).
5. Magnetic will not stay over patched surfaces.
6. Do not use over simulated wood finishes (veneer finishes on vehicles) .

Temperature:

1. The temperature of the surface of the vehicle is unimportant, however the sign should be at least 60 degrees Fahrenheit for installation.

Maintenance & Cleaning:

1. Remove magnet at least once a week and clean both the magnetic & steel product.
2. Wipe dry both the sign and vehicle. Use a mild detergent in warm water to clean the vinyl surface of the sign.
3. On rainy or humid days remove the magnetic signs.
4. Keep a good coat of wax on the steel surface.

Storage:

1. Store magnetic pieces either flat or in rolls. When storing in rolls, wrap coated surface on the outside to avoid the possibility of wrinkles. Make sure the inside diameter of the rolls is no less than 3" .

Rolling:

1. To protect the sign from damage, avoid wrinkles. Roll the sign with the printed surface on the outside.